



Changing **FAX Numbers** on a Sharp Multi Function Printer



Log in to Device Webpage by typing the Printers IP address into your browser.


Login as an administrator. (PW: admin)

Checking the **Device FAX Number**




Select **System Settings** in the menu on the top

Select **Image Send Settings** in the submenu



Select **Common Settings**




Select **“Own Name & Destination Set”** in the menu on the left

Edit the Fax number to include:
1 + Area Code + Phone Number

Choose **Submit**

Checking the Destination **FAX** Numbers in the Address Book



Select the **Address Book** Tab
Select the Address to be edited

The Address Registration menu will appear

